


# **MultiDOT**

Temperature and Humidity Sensor



Pack Contains: 1x MultiDOT, 1x Adhesive Pad, 1x Stand

## **Safety and Guidelines**

 $\label{eq:MultiDOT requires BCM for operation and is intended for internal use only. \\$ 

MultiDOT requires a good ZigBee connection with BCM. Once joined the connection strength is shown on screen by the signal bars.

# Compatibility

The MultiDOT is an ancillary device for use in conjunction with BCM. MultiDOT wirelessly connects using the ZigBee protocol to BCM

For more information, get in touch with us via our website: www.vericonsystems.com

#### **Device Information**

MultiDOT

Model: MDA

Required Batteries: 2x AAA Batteries Zigbee 802.15.4 Compatible

Vericon Systems

Unit 5, Churchill Industrial Estate, Churchill Road, Cheltenham, GL53 7EG.
www.vericonsystems.com

Support: support@vericonsystems.com or visit our website.

#### Installation

- 1. Insert two AAA batteries into MultiDOT and replace the cover.
- Before installing MultiDOT, fully install BCM and ensure it is connected to the internet.

  (Both the LEDs on BCM should be on and not flashing)
- 3. Scan the QR code on BCM to enter the app. (Or navigate to app.vericon.co.uk and input the BCM's serial number)
- 4. Scroll across the tabs to located the "Devices" tab.
- 5. Click "Install New Device".

#### Installation

- Input MultiDOT's serial number.(This is located in the battery compartment)
- 7. Follow the on-screen instructions.
- 8. Input the location of MultiDOT.
- When the app asks, hold down the button on the top of MultiDOT until the signal bars begin to flash (around 10 seconds).
- Once the app shows that MultiDOT is connected, it can be placed in-situ using either the included stand or adhesive pad.

## FAQ and Troubleshooting

Where should MultiDOT be situated?

MultiDOT should be placed near any areas which have an issue with mould, damp or condensation.

#### My MultiDOT is not connecting?

MultiDOT may be too far away to connect to BCM, bring MultiDOT closer to connect and then re-install in the original location. Once secured in the desired location, press the button on the top and wait for 5 seconds for the signal indicator to update.

For more troubleshooting, please visit our website